

Everbrite Instructions

Surface Preparation

Dilute 50ml to 1 bucket of water. Neutralise the area with ERW-BD using the microfiber cloth and rinse with fresh water. This will balance the PH. Allow to dry.

Coating

Pour the Everbrite coating into a metal kettle or pail. Soak the lint free applicator cloth into the coating until saturated. Wring out the cloth to expel excess coating. Wipe the coating onto the surface. Do not use a scrubbing action. Pay particular attention to screws, fixing and joints. Allow 20 to 60 minutes to dry, depending on temperatures. Do not attempt to go over areas you feel you may have missed during the drying period, they will be covered on the next coat.

If possible, leave first coat on for 24 hours before the second coat is applied.

Apply the second coat using the lint free applicator cloth. Ensure there is plenty of coating on the cloth. If the cloth runs dry, you will risk tearing the first coat.

If tearing of the first coating occurs, simply apply more coating to affected area.

The coating usually dries in 20 to 60 minutes, depending on air temperature and will be fully cured in 24 hours.